

Kessick Estate Designs Installation Instructions

Kessick Estate Designs consist of fully assembled wine rack components, configured in a specific design layout. The individual components stack on top of each other, are anchored together, and then are secured to the wall. Reading, understanding and following these instructions will help to insure a safe efficient installation.

Tool recommended for installation:

<ul style="list-style-type: none"> • Cordless Drill • #2 Square Drive Tip • 1/8" Drill Bit • Air Compressor 	<ul style="list-style-type: none"> • Brad Nailer, 18g • Tape Measure • Pencil • Level 	<ul style="list-style-type: none"> • Shims • Quick-Grip Clamps • Stud Finder
---	---	---

Parts and Components in Estate Design wine rack system:

<ul style="list-style-type: none"> • Base units • Wall Units • Base Platform • Base Molding • Crown Cap Molding 	<ul style="list-style-type: none"> • Face Cap • #10 x 3" Screws • #6 x 1 1/4" Screws • Fast-Cap Screw covers 	<p>OPTIONS MAY INCLUDE:</p> <ul style="list-style-type: none"> • End Panels • LED Lighting • 1/4" Cabinet Back
--	--	---

- Review the wine rack design and confirm all components, parts and upgrade options are accounted for.
- Set 3" base platforms on hard level floor in the area you want the wine racks to be installed. Screw the base platforms together. Level the base platform, shim or scribe if necessary. Level left/right and front/back. Screw the base platform to the wall.
- Identify all the Base units (31.5" H). Set Base Units on Base Platform, clamp Base units together and confirm they fit the footprint of the Base Platform. Anchor Base Units together using supplied 1 1/4" screws or brad nails. Apply screws in inconspicuous locations such as under shelf, under bottle supports, under top stretcher, etc. Screw or nail Base units to base platform below.
- Temporarily anchor base unit to wall by driving supplied 3" screw through 3" installation rail into wall stud (ID wall stud with stud finder if necessary), do not over tighten temporary screw.
- Identify all the Wall units (50.25" H). Set Wall Units on Base Units. Clamp Wall units together and confirm they fit the footprint of the Base Units. Anchor Wall Units together using supplied 1 1/4" screws or brad nails. Apply screws in inconspicuous locations such as under/above bottle supports, under top stretcher, etc. Screw or nail Wall units to base Units below.

- Plumb the face, and sides of the wine racks with a level and anchor wall units to the room wall by driving supplied 3" screws through 3" installation rail into wall stud (ID wall stud with stud finder if necessary). It may be necessary to shim behind installation rail to achieve a plumb wine rack. Finish securing base units to room wall
- Using miter saw and brad nailer, cut and apply base molding and crown cap molding.
- Identify face cap molding. Using brad nailer, apply face cap molding to seams between components.
- Design diagram provide further details and specifications. Contact Kessick LLC at 864-297-1911 with any installation questions.

