

## Package Content:

- Straight pegs (x18)
- #8 Wood screws (x4)
- Backer panel (x1)
- Faceplate (x1)
- Drywall anchors (x4)

## Recommended installation tools (not included):

Tape measure, level, 1/8" drill bit, electrical drill, and stud finder.

## Recommended fastener applications:

**Drywall anchors** - Use for installing rails to drywall if studs are not present in the desired location. Do not use drywall anchors to secure rack to a stud.

**Wood screws** - Use wood screws to secure rails to wall studs or wood panels. Do not use wood screws on drywall unless the screws will be secured to a stud. Concrete or masonry applications are not recommended.

**Concrete, brick or stucco** - 3/16" x 1-1/4" masonry screw or #8 x 1-1/4" screw with the proper concrete anchors (screws are not included).

## **IMPORTANT!** Before installing Diamond Fusion Panel, do the following:

Check the package contents for missing or damaged items. Contact customer services at 1 (800) 343-9463 for questions or concerns.

**Step 1** - Locate wall studs by using a stud finder.

**Step 2** - Place the backer panel against the wall in the desired location.

**Step 3** - Use a level and a 1/8" drill bit to mark mounting location.

**Step 4** - Drill drywall anchors into the wall and then mount the backer panel with wood screws; OR directly secure the panel to studs with wood screws.

**Step 5** - If applicable, remove the faceplate's protective film.

**Step 6** - Line up faceplate and backer panel holes and then secure faceplate using pegs.

**Step 7** - Congratulations! You have completed your Diamond Fusion Panel wine rack installation!

